



# R36s Game Console Manual

## Functional Description



### Combination Key Description

Brightness Adjustment	--- R3 + UP/DOWN
Save/Read Game	----- SELECT + L1/R1
Save Location	----- SELECT + UP/DOWN
Exit Game	----- SELECT + START
Enter ESTROARCH	----- SELECT + X/L3 + R3
Pause the game	----- SELECT + A
Restart the game	----- SELECT + B

# Special Instruction

power on/off & memory card description

1. You must insert the system card into TF1-OS position before starting up, then press the power key to power on and enter the system.
2. Insert the copied game data card into the TF2-GAME bit, after booting into the system, select(OPTIONS-ADVANCED-SWTCH TO SD2 FOR ROMS), and display the content of the game card after running.

## Warning instructions

Without a system card, the device will only turn on yellow light without picture Display. At this time, you must insert the system card and press the reset key To enter the system.

If the software sets SD2 and pulls out TF2-GAME and turns on, it will also appear that the system does not wake.

## Charging instructions

1. When the host red light flashes, please charge in time. After connecting DC to charge, the indicator shows static red.
1. If the red light starts flashing and does not charge in time, the host will be powered off automatically after about an hour of service. Please press the power key for 12 seconds until the green light is turned off and recharged. After about an hour. It will turn on normally. So please charge it in time.

## Classical parameter

<b>64bit</b> Four core Cortes-A7 1.5GHz CPU	<b>5V 2A</b> Fast charging	Trigger structure new feel
<b>3.5 inches</b> 640*480 HD screen	<b>Dual TF card</b> Supports max 256 GB	<b>10</b> Emulators

## Configuration List

Video game handheld	*1
Type-c data line	*1
Certificate	*1
Product description	*1